

## For SEL Controller Teaching box





## ■ Specification

Item	Details			
Model	SEL-T	SEL-TD	SEL-T-J	SEL-TD-J
Connector converter cable (%1)	Not Required		Attached	
3—position enable switch	No	Yes	No	Yes
ANSI specification	Non-compliant	Compliant	Non-compliant	Compliant
CE mark, UL specification	Compliant			
Corresponding controller (*2)	XSEL (** Excluding J / JX type)	п	PSEL ASEL SSEL	XSEL TT (** Excluding J / JX type)
Position input	0			
Programming input	0			
Parameter rewrite	0			
Each type of stator	0			
Display	20 characters × 4 lines			
Operating ambient temperature & humidity	0-40°C 10-90%RH (Non condensing)			
Protective structure	IP54			
Cable length	5m			
Mass	Approx. 0.4kg (Excluding cable)			

<sup>(\* 1)</sup> A connector converter cable is required when connecting SEL-T / SEL-TD to PSEL, ASEL, SSEL. Connector converter cable type: CB-SEL-S J002 (Cable length: 0.2m)

(\* 2) XSEL-J / JX type controller cannot be used.

## ■ Outline View

