
■ Model :RGW-□/RACON/RPCON/RABU/REXT

For RCA2/RCA/RCL/RCP3/RCP2 **Network Controller** 




ROBONET is a new type of control unit that freely operates ROBO Cylinders via a field network. They have less wiring and are more compact than past controllers, and by DIN rail mounting make it possible to vastly reduce wiring and installation labor.


### **Features**



# **Reduced Wiring**

By connecting each line of the I/O cables to lines wired to the PLC terminals with the field network, wiring processing is completed with one dedicated cable. Also, since the unit can be coupled by just connecting with the unit connection board, the controller wiring work is greatly simplified.





**503** ROBONET



Controllers
Integrated

Roo
Type

Mini

Standard

Controllers
Integrated

# The robot can be moved by directly specifying numeric values for the move position/velocity/acceleration and other data.

Besides the conventional method of moving the robot to pre-taught positions it is also possible to operate the robot by sending information as a string of numeric data that contains position, velocity, acceleration, etc. values. This is effective for cases such as when the move position changes with each piece or when one wants to move the robot to an arbitrary position.

	ROBONET controller	Standard controller (ACON/PCON)
Movement by specifying positions	0	0
Movement by specifying direct values	0	
Specifying speed/acceleration	0	(Not for PIO)
Current value output	0	(Connectable with serial communication)

\*ROBONET operates through a field network,

# **Ultra-compact**


Each unit is an ultra-compact size of 34mm wide by 100mm high x 73mm deep. Also, since there is no base unit and the main unit is coupled with connectors, the controller takes up little space for installation even if there are many units.



# Can operate with a maximum of 16 axes.

Up to 16 controllers can be connected to one communication unit (Gateway R unit).


RACON units (controllers for RCA) and RPCON units (controllers for RCP2) can also be used together.



# Controllers can be multiplexed.

Controllers can be multiplexed using an optional extension unit, so many axes can be connected even if there isn't much horizontal space.

Also, non-ROBONET controllers (SCON, PCON-CF, ERC2) can be connected to a ROBONET Gateway unit using the same extension unit.



# Simple absolute unit, when home return is not required

The simple absolute R unit allows operation for incremental specification axes without home return. Users can back up actuator encoder data even if the power is shut off, by installing a simple absolute R unit to a RACON unit (controller for RCA) or RPCON unit (controller for RCP2).





# Mounting the DIN rail

The controller is installed with DIN rails, so it can be fastened and removed with one touch.

IAI

Controllers

PMEC
/AMEC
PSEP
/ASEP

ROBO
NET

ERC2

PCON


ACON

SCON

sales@electromate.com



### System configuration



## **ROBONET Extension Unit**

If multiple ROBONET extension units (optional) are linked together they can reduce the lateral width needed. It is also possible to connect individual controllers, such as SCON, etc. via the ROBONET.


[Unit Multiplex Set]

**Model: REXT-SIO** 

(Set Contents)

ROBONET Extension Unit (Model: REXT) 2 pc Unit Link Cable 1 pc

(Model: CB-REXT-SIO010)




[Controller Connecting Set]

Model: REXT-CTL

(Set Contents)

ROBONET Extension Unit (Model: REXT) 1 pc Controller Connection Cable 1 pc

(Model: CB-REXT-CTL010)



505 ROBONET



### Configuration unit

Required ROBONET units are ordered individually, and assembled as you see fit. If actuators are added later, they can be easily added simply by adding a RACON/RPCON unit.




Unit Name	Unit Name  Description  This unit is for connecting to a field network. Users can select from 4 types: DeviceNet, CC-Link, ProfiBus, and SIO. *This unit is required for using ROBONET.				
RACON unit					
RPCON unit	This controller operates the RCP2 actuator. (One unit is necessary per actuator axis.) The incremental specification is the standard, but the simple absolute specification can also be used if the simple absolute R unit is used with it.	P510			
Simple absolute R unit when the power is turned off.		P511			
Extension unit	This unit makes it possible to reverse ROBONET connections, connect unit controllers (SCON/PCON-CF) to ROBONET, and conduct operation from a network.	P511			

# Ordering Method/Precautions

Required ROBONET units are ordered individually and assembled by the customer. Consequently, they can be added to or changed later.

<Ordering example> The following 2 actuator axes can be operated through CC-Link. The models that would be best operated with the absolute specification are as follows.



■ Gateway Parameter **Setting Tool** 

A gateway parameter setting tool is necessary to set up the network when ROBONET is connected to a field network. This tool can be acquired at no cost.

- (1) Download from the IAI website, or
- (2) Acquire PC compatible software (included on CD).

A cable (cable included with PC software, model: CB-RCA-SIO050+RCB-CV-MW) is required to connect the PC to the controller when using the gateway parameter setting tool. If you do not have the PC software, please purchase a cable.

■ PC Compatible Software Teaching Pendant

Compatible PC software or a teaching pendant is required to enter position data, etc. to a ROBONET controller unit. ROBONET compatible PC software (Model: RCM-101-MW/USB) version is Ver. 6.00.04.00 or later. Teaching pendant compatible models and versions include: RCM-T and Ver. 2.06 and later, model: RCM-E/RCM-P and Ver. 2.08 and later. Model: CON-T is compatible with all versions from the earliest version.

Consult with our Sales Division if the version your equipment has needs to be updated.

IAI













































































## Operation Mode

ROBONET operates upon receiving commands from the PLC via the field network.

The following four operating modes are available. Select the most suitable mode for the operation or the control method.

	Name	Description			
1	Positioner mode (1,2)  In this mode, operation is done by specifying position numbers, whose position data, speed, and acceleration have been entered to the position table in advance.  A maximum of 768 position points can be saved.				
2	Simple direct input mode  Simple direct input mode  The position data is specified directly using a numerical value; the other settings, such as speed, acceleration, deceleration, positioning band, and pushing current limit are specified using a predefined position number.  A maximum of 768 position points can be saved.				
3	Direct input mode  The position data, speed, acceleration, deceleration, positioning band, an are all specified directly using numerical values. Since the settings are spentiment of points that can be set.				
4	Solenoid valve mode (1,2)	The number of positioning points is limited for a simpler operation.  You can operate it using the same controls as a solenoid valve, just by sending a command with the target position number (start signal not required).			

### List of functions for operation modes

Item	Operation mode	Positioner 1 Mode	Simple immediate data Mode	Direct number designation mode	Positioner 2 Mode	Solenoid Valve Mode 1	Solenoid Valve Mode 2
Each axis fi	eld (both input and output)	4 we	ords	8 words	2 words	2 wo	ords
Fixed field (	both input and output)	n input and output) 8 words 8 words (Command field usable) (Command field usable) (Command field usable) (Command field usable)					
Number of s	Number of set positions		768 positions/axis	-	768 positions/axis	7 positions/axis	3 positions/axis
Position No	designation operation	0	0	×	0		
Position da	ta direct designation	×	0	0	×	,	•
Direct desig	nation of speed and acceleration/deceleration speed	×	×	0	×	,	•
Direct desig	gnation of positioning band	×	×	0	×	,	•
Pushing op	eration	0	0	0	0		)
Completed	position No. monitor	0	0	×	0		)
Zone outpu	t monitor	0	0	0	0		)
Position zor	ne output monitor	0	0	×	0		)
Teaching fu	nction	0	×	×	0	,	•
Jog operati	on	0	0	0	0	,	•
Incrementa	I operation	0	0	0	0	,	•
Status signa	al monitor (*1)	0	0	0	0	>	•
Current pos	sition monitor (*1)	0	0	0	0	,	•
Alarm code	monitor (*1)	0	0	0	0	,	•
Speed and	current monitor (*1)	×	×	0	×	,	•
Each axis m	nonitoring function in ode (*2)	0	0	0	0		
	Hand shake	0	0	×	0		
Command	Position table Reading/writing of data	0	0	×	0	(	)
	Reading the current position	×	×	×	×	,	•
	Broadcast	0	×	×	0		
Max. value	for position data designation	9999.99mm (When command is used)	9999.99mm	9999.99mm	9999.99mm (When command is used)		99mm nand is used)
Number of a	axes that can be connected	16	16	8	16	1	6

- Each status signal monitor, current position monitor, alarm code monitor, and speed/current monitor can be viewed by accessing to each \*1: address of Gateway unit via PLC.
- \*2: Traditionally, monitoring each axis in AUTO mode is unavailable. However, monitoring each axis with Mode switch at "AUTO" is available with ROBONET by connecting the special touch panel to the TP connector.
- Independent acceleration and deceleration settings are not available. The setting applies to both accelerating and decelerating speeds.

 $507_{\mathsf{ROBONET}}$ 

## Configuration unit (Gateway R unit)

# Gateway R Unit for DeviceNet

A communications unit to operate ROBONET via DeviceNet.


## Model RGW-DV

Specifications

s		Item	Spec	ifications		Item	Specifications			
	Po	wer	DC24V ±10%		suc		Comm. Speed	Max. network length	Max. branch length	Total branch length
	Current		600mA max.			Comm.	500kbps	100m		39m
	s		DeviceNet 2.0-cer	tified interface module	Specifications	cable length (*1)	250kbps	250m	6m	78m
	Comm.	Comm. Standard	Group 2 only serve	er	DeviceNet S		125kbps	500m		156m
3	Comm. Standard		Insulated node operating on network power supply				Note: Whe	n using a larg	e cable for D	eviceNet
		Comm. Spec.	pec. connection	Bit strobe	_	No. occupied nodes	1 node			
	eNet			Polling	ent ints	Ambient op. temperature 0~40°C				
1:	DeviceNet			Cyclic	onme	Ambient op. temperature Ambient op. humidity Ambient op. environment	95% RH or	below (non-co	ondensing)	
ľ.		Comm. Speed	500k/250k/125kbps (switchable by software)		Envir Pequ	Ambient op.	No corrosi	ve or flammabl	e gasses, oil i	nist, or dust.
*1 If you wish to use T-junction comminstructions manual for your maste			nunication, see the		otection class					
	monacon managa isi year mason ami si i zer		Weight		140g					
					Ac	cessories	Terminal re Network c	esistor board (r onnector, Eme	nodel TN-1) rgency stop o	onnector

### Network cable

MSTBA2.5/5-G-5.08 ABGY AU (Made by: Phoenix Contact)



Connector on Cable Side MSTB2.5/5-ST-5.08 ABGY AU Black Blue (Made by: Phoenix Contact)

= Standard accessory

Pin Color	Description
Black	Power cable negative (-) side
Blue	Comm. data Low side
-	Shield
White	Comm. data High side
Red	Power cable plus (+) side

A communications unit to operate ROBONET via CC-Link.

### Cable connector-compatible wiring

Oubic comicotor (	Subjection companie wing						
Item	Description						
Wire diameter	Twisted wire: AWG24-12 (0.2~2.5mm²)						
Stripped wire length	7mm						

# Gateway R Unit for CC-Link






ns 🗌	Item		Specifications		Item	Specifications					
	Power Supply DC24V ±10% g Error Contr		Error Control Method	CRC (X16+X12+X5+1)							
	Cur	rent consumption	600mA max.	ecifications	Station occupancy	Remote device stations: ×1, 4 st.; ×4, 2 st.; ×8, 2 st					
		Comm. Standard	CC-Link Ver2.0 (*1)	िक्र	Comm. Cable		10M	5M	2.5M	625k	156k
	Suc	Comm. Speed	10M/5M/2.5M/625k/156kbps (switchable by software)	į	Length (*2)	Total Cable Length (m)	100	160	400	900	1200
1	Specifications	Comm. Method		ပ္ပ	Comm. Cable	Dedicated CC-Link cable					
	Speci	Sync. Method	Frame synchronization method	ま	Ambient op. 5 E temperature 0~40°C						
1	CC-LINK	Encoding Method	NRZI	Invironment equirements	Ambient op. humidity	95% RH or below (non-condensing)					
1	3	Transf. Type	Bus format (EIA RS485 compliant)	Envir Begui	Ambient op. environment	No corrosive o	or flamm	able ga	sses, oi	l mist, o	or dust.
	Transf. Format HDLC compliant		_	otection class	IP20						
	*1 Certification acquired *2 If you wish to use T-junction communication, see the instruction manual for your master unit or PLC.		We	eight	140g						
*2			Ac	cessories	Terminal resis Network con Terminal resis	nector,	Emèrge	ency st	op coni	nector	

### **Network cable**

Connector on Gateway Side: Connector on Cable Side: MSTBA2.5/5-G-5.08AU MSTB2.5/5-ST-5.08 ABGY AU (Made by Phoenix Contact) (Made by Phoenix Contact) = Standard accessory



Signal Name	Description				
DA	Communication line A				
DB	Communication line B				
DG	Ground				
SLD	The shield and cable's shield are connected, then they are connected to "FG" and the chassis.				
FG	Frame ground Connected to "SLD" and the chassis.				

Cable connector-compatible wiring

Cable connector compatible wiring							
Item	Description						
Wire diameter	Twisted wire: AWG24-12 (0.2~2.5mm²)						
Stripped wire length	7mm						

IAI













































# Configuration unit (Gateway R unit)

# Gateway R Unit for ProfiBus

A communications unit to operate ROBONET via ProfiBus.

## Model RGW-PR

Specifications

Specifications			Item	Specifications		
F	ower Supply	DC24V ±10%		ronment irements	Ambient op. temperature	0~40°C
	Current Consumption	600mA max.		ironn		95% RH or below (non-condensing)
,	Comm. Standard	DP slave		Envi	Ambient op. environment	No corrosive or flammable gases, oil mist, or dust.
ļ	Comm. Speed	9.6kbps~12Mbps			otection class	IP20
ifica		9.6kbps	1500m	W	eight	140g
Specifications	Comm.	500kbps	400m	Accessories		Terminal resistor board (model TN-1) Emergency stop connector
313	Cable Length	1.5Mbps	200m			
ProfiBus		3Mbps	200m			
"		12Mbps	100m			

### Network cable

Mini
Standard
Controllers
Integrated
Rocc
Type
Mini
Standard
Controllers
Integrated
Table/Arm
/Flat Type
Mini
Standard

Connector on Gateway Side: D-Sub connector, 9-pin socket side



Pin No.	Signal Name	Description	Pin No.	Signal Name	Description
3	B-Line	Communication line B (RS485)	6 +5V		+5V output (insulated)
4	RTS	Request send	8	8 A-Line Communication line A (RS485)	
5	GND	Signal ground (insulated)	Housing	Shield	Connected to the cable's shield and the chassis.

<sup>\*</sup> The matching connector (D-Sub 9-pin connector) is not included. \* Pins 1, 2, 7, and 9 are not connected

# Gateway R Unit for SIO



A communications unit for operating ROBONET from an XSEL controller or a Modbuscompatible communications unit, via serial communication.

### Model RGW-SIO

Specifications

5	Item	Specifications		Item	Specifications
Specifications	Power Supply	DC24V ±10%	nt nts	Ambient op. temperature	0~40°C
	Current consumption	600mA max.		Ambient op. humidity	95% RH or below (non-condensing)
	Comm. Type	RS485-compliant (Modbus protocol) 1:1 communication connection	iviro quire	Ambient op. environment	No corrosive or flammable gases, oil mist, or dust.
	Comm. Method	Asynchronous method, half-duplex	Er Re	Protection class	IP20
SIO Sp	Comm. Speed	230.4kbps max.		ight	140g
S	Cable Length	100m or less		cessories	Terminal resistor board (model TN-1) Network connector, Emergency stop connector
	Recommended cable	2 pairs of twisted pair cables (shielded)			• • • • • • • • • • • • • • • • • • • •



5	57	57	57
<b>B</b>	<b>1</b>	<b>®</b>	<b>8</b>
		$\sim$	
FG	SG	SB	SA

Signal Name	Description					
SA	Communication line A (+positive side) Built-in RS485-compli					
SB	Communication line B (-negative side)	terminal resistor (220Ω)				
SG	Signal ground					
FG	Frame ground connected to the chassis.					

### Cable connector-compatible wiring

Item	Description
Wire diameter	Twisted wire: AWG28-16 (0.14~1.5mm²)
Stripped wire length	7mm

**Network cable** 

MC1.5/4-G-3.5

MC1.5/4-ST-3.5 (Made by Phoenix Contact) = Standard accessory



## Configuration unit (Controller unit)

# **RACON** unit

### Controller for RCA2/RCA series



Controller unit that is used for RCA2/RCA actuator operation with ROBONET.

Model RACON-12-3

- \* In Model ①, input a motor power output. (See the following table.)
  - ② will need the code "HA" or "LA" specified when a high acceleration/deceleration or power saving actuator is to be used. (Otherwise, leave it blank.)

    ③ input "ABU" only when a simple absolute unit is used. (Otherwise, leave it blank.)

Model	Compatible actuators					
RACON-22-3	RCL-SA1L / SA4L / SM4L / RA1L					
RACON-52-3	RCL-SA2L / SA5L / SM5L / RA2L					
RACON-102-3	RCA2-SA3C / RN3N / RP3N / GS3N / GD3N / SD3N / TC3N / TW3N / TF3N / TA4 RCL-SA3L / SA6L / SM6L / RA3L					
RACON-202-3	RCA-SA4 / SS4 / SA5 / SS5 / RA4 -20 / RG 4 -20 / A4R / A5R RCACR-SA4C / SA5 RCAW-RA4 -20 RCA2-SA4 / SA5 / TA6					
RACON-20S2-3	RCA-RA3 / RG 3 RCAW-RA3 RCA2-SA4 / TA5					
RACON-302-3	RCA-SA6 / SS6 / RA4 -30 / RG 4 -30 / A6R RCACR-SA6 RCAW-RA4 -30 RCA2-SA6C / TA7C					

### **Specifications**

	Item	Specifications		Item	Specifications
	Power Supply	DC24V ±10%		Ambient op. temperature	0~50°C
S	Power Supply Capacity	5.1A max. (depends on the actuator)	ironment uirements	Ambient op. humidity	95% RH or below (non-condensing)
ations	Operable Actuators	RCA series	inviro equire	Ambient op. environment	No corrosive or flammable gases, oil mist, or dust.
li≌	Positioning Points	768 points	ъĒ	Protection class	IP20
Speci	Backup memory	EEPROM	We	ight	200g
	Position Detection Method	Incremental encoder		cessories	ROBONET connection board (model JB-1),
General	Solenoid brake force-release	Brake release switch			Power connection board (model PP-1)
9	Motor Cable	Model: CB-ACS-MA			
	Encoder Cable	er Cable Model: CB-ACS-PA			

## **RPCON** unit

# Controller for RCP3/RCP2 series



Controller unit that is used for RCP3/RCP2 actuator operation with ROBONET.

Model **RPCON-1-2-3** 

- $^{\star}$  In Model  $\textcircled{\scriptsize 1}$  , input a motor type. (See the following table.)
  - ②input "ABU" only when a simple absolute unit is used. (Otherwise, leave it blank.)
  - ③should have the code "H" when an RCP3-SA4, SA5, SA6, or an RCP2(RCP2CR)-SA5 or SA6 is to be connected.

Model	Compatible actuators			
RPCON-20P-@	RCP2-RA2C / GRSS / GRLS / GRS RCP3-SA2A / SA2B / RA2A / RA2B			
RPCON-28P-2	RCP2-GRM / GR3LS / GR3SS / RTB / RTC / RTBL / RTCL RCP3-SA3C			
RPCON-28SP-2	RCP2-RA3C / RGD3C			
RPCON-35P-2-3	RCP3-SA4 / TA5			
RPCON-42P-@3	RCP2-SA5 / SA6 / SS7 / BA6 / BA7 / RA4C / RG 4C / GR3LM / GR3SM RCP3-SA5 / SA6 / TA6 / TA7 RCP2CR-SA5C / SA6C / SS7C RCP2W-RA4C			
RPCON-56P-2	RCP2-SA7 / SS8 / RA6C / RG 6C / RCP2CR-SA7C / SS8C RCP2W-RA6C			

### Specifications

	Item	Specifications		Item	Specifications	
	Power Supply	DC24V ±10%		Ambient op. temperature	0~50°C	
,	Power Supply Capacity	2A max.	Environment Requirements	Ambient op. humidity	95% RH or below (non-condensing)	
Specifications	Operable Actuators	RCP2 series		Ambient op. environment	No corrosive or flammable gases, oil mist, or dust.	
	Positioning Points	768 points	<u>ڇ</u> س	Protection class	IP20	
bec	Backup memory	EEPROM	Weight		200g	
	Position Detection Method	Incremental encoder	Accessories		ROBONET connection board (model JB-1),	
General	Solenoid brake force-release	Brake release switch			Power connection board (model PP-1)	
	Motor Cable	Model: CB-RCP2-MA				
	Encoder Cable	Model: CB-RCP2-PB				

IAI

ROBONET **510** 



# Configuration unit (Simple absolute R unit/Extension unit)

# Simple absolute R unit



A data backup battery unit that can be attached to an RACON or RPCON controller to use an incremental actuator as an absolute type.

\*1 One unit of the simple absolute R unit is required per RACON/RPCON unit.

### Model RABU (for RACON and RPCON)

\* When preparing a simple absolute R unit together with a controller unit (RACON/RPCON), write down "-ABU" to the end of the controller model, of which the simple absolute unit is installed.

Specifications

s		Item Specifications			Item	Specifications			
		Power Supply	DC24V ±1					Ambient op. temperature	0~40°C
Specifications	SI	Current consumption	300mA m	ax.			eme	Ambient op. humidity	95% RH or below (non-condensing)
	atio	Battery used	Ni-MH ba	ttery, nickel	-hydrogen	cell battery	nviro auir	Ambient op. humidity Ambient op. environment	No corrosive or flammable gases, oil mist, or dust.
	ecific	Charging time	Approx. 78 hours			шæ	Protection class	IP20	
		Battery life	3 yrs			W	eight	330g	
General	Genera	Maximum rpm for absolute data retention	800	400	200	100	Δς.	cessories	ROBONET connection board (model JB-1)
		Absolute Data Retention Duration (h)	120	240	360	480			simple absolute connection board (model JB-1) power connection board (model PP-1)

# **Extension Unit**



When too many ROBONET units are connected horizontally to fit into the controller board, use this unit to split them in the middle with a cable to create another row.

In addition, by attaching the extension unit to the end of the linked ROBONET units and using an external controller cable, you can operate a standalone controller SCON like any other ROBONET controller, over the network.

### Model REXT (for RPCON and RACON)

Specifications

	Item		Specifications
	General Specifications	Power Supply	DC24V ±10%
	Gen Specific	Current consumption	100mA max.
	달	Ambient op. temperature	0~40°C
1	a a	Ambient op. humidity	95% RH or below (non-condensing)
	Environment Requirements	Ambient op. environment	No corrosive or flammable gases, oil mist, or dust.
	핕	Protection class	IP20
	Weight		140g
	Acc	essories	ROBONET connection board (model JB-1), Power connection board (model PP-1)

(Note) The cable used is different depending on whether you are creating a new row of linked units, or connecting a standalone controller.
For more information, see the ROBONET extension unit on P505.








# External dimensional drawing

External dimensions of Gateway R unit, RACON unit, RPCON unit, Simple Absolute R unit, and Extension unit are same.



### Option


### **Teaching Pendant**

A teaching device with functions for Features inputting positions, performing test runs, and monitoring.

CON-PT-M (Touch panel teaching pendant) Model

CON-T (Standard type)

RCM-E (Simple teaching pendant) ■ Configuration



CON-T Options Wall-mounting hook Model HK-1

PC Software (CD)

Strap



# CON-PT-M CON-T RCM-E 48.5 **Specifications**

CON-T

0

RCM-E

0

Item	CON-PT-M
Data Input	0
Actuator motion	0
Ameleiand On anatina	


Actuator motion			0			
Ambient Operating Temp./Humidity	Temp: 0~40°C; Humidity: 85% RH or below					
Ambient Operating Atmosphere	No corrosive gases. Especially no dust.					
Protection class	IP40	IP54	_			
Weight	Approx. 750g	Approx. 400g	Approx. 400g			
Cable Length		5m				
Display	3-color LED touch panel with backlight	20 char. × 4 lines LCD display	16 char. × 2 lines LCD display			
Standard Price	-	-	-			

# **PC Software (Windows Only)**

A startup support software for inputting positions, performing test runs, and monitoring. ■ Features With enhancements for adjustment functions, the startup time is shortened.

RCM-101-MW (with external device communications cable + RS232 conversion unit) Model

Note:



Note: Only version 6.00.04.00 or later can be used with ROBONET. ■ Configuration USB adapter RCB-CV-USB 3m 5m

External device

communications cable

CB-RCA-SIO050 IAI

USB cable

CB-SEL-USB030







### Option

# **DC24V Power Supply**

### Features

A 24V power supply for ROBO Cylinder that can output 17A of momentary current. Power supply units can be operated in parallel, and up to 5 units can be added if a unit runs out of capacity.

Model

ontrollers ntegrated Rod Type Mini Standard

PMEC /AMEC
PSEP /ASEP
ROBO NET
ERC2
PCON
ACON
SCON
PSEL
ASEL

**PS-241** 

(100V input model)

PS-242

(200V input model)

### Actuator vs. Power Supply Current

	Actuator type	Power Supply Current [A]		No. of connectible units for each unit of PS-24	
Controller type				Simultaneous servo ON for all axes*	No simultaneous servo ON for all axes*
RPCON PCON	RCP2, all models (note)	Rated (= Maximum)	2	8	8
RACON ACON	SA4, SA5 (20W)	Rated	1.3	3	6
		Maximum	4.4		
	SA6 (30W)	Rated	1.3	4	6
		Maximum	4		
	RA3 (20W)	Rated	1.7	3	5
		Maximum	5.1		
	RA4 (20W)	Rated	1.3	3	6
		Maximum	4.4		
	RA4 (30W)	Rated	1.3	4	6
		Maximum	4		



### Spare parts

When spare parts are necessary after purchasing the product, such as when replacing a cable, refer to a list of the models below.



ROBONET connection board (simple absolute connection board) Model JB-1



Terminal resistor board Model TN-1



Power connection board Model PP-1

### Motor cable for RCP2


The standard cable for the motor cable is the robot cable. Selection is available CB-RCP2-MA \* Enter the cable length (L) into

Min. bend radius r = 50 mm or larger (when movable type is used) (20) (20) (14) CN3 CN1 CN3 Mechanical side


### Encoder Cable/Encoder Robot Cable for RCP2

\*The standard encoder cable is the normal cable. The robot cable is selectable as an option.

\* Enter the cable length (L) into \( \sum \subseteq \subseteq \). Compatible to maximum of 20 meters. Ex.: 080 = 8m Model CB-RCP2-PB /CB-RCP2-PB -RB





Min. bend radius r = 50 mm or larger (when movable type is used)



# Motor-encoder integrated type cable for RCP3/RCP2 (Limited to RCP2-GRSS/GRLS/GRST/SRA4R/SRGS4R/SRGD4R types)

Enter the cable length (L) into  $\Box\Box\Box$  . Compatible to a maximum of 20 meters. Ex.: 080 = 8 m Model CB-PCS-MPA






513

<sup>\*</sup> Refers to the first servo ON after power-up. (Note) Excluding HS8C, HS8R, and RA10C \* For PSEL/ASEL, this is different depending Please inquire for details.

<sup>\*</sup> Only the robot cable is to be used in a cable track.

# ROBONET Controller Spare parts Motor Cable for RCA \* Enter the cable length (L) into $\Box\Box\Box$ . Compatible to a maximum of 20 meter Model CB-ACS-MA No. Signal Color Wire 1 U Red 2 V White Current Glack (crimped) | Wire | Color | Signal No AWG22 | Red | U | 1 (crimped) | White | V | 2 ¹**₽** □ Controller side Min. bend radius r = 50 mm or larger (when movable type is used) Encoder Cable/Encoder Robot Cable for RCA \*The standard encoder cable is the normal cable. The robot cable is selectable as an option. \* Enter the cable length (L) into \( \subseteq \subseteq \). Compatible to maximum of 20 meters. Ex.: 080 = 8m Model CB-ACS-PA /CB-ACS-PA -RB 0 () Min. bend radius r = 50 mm or larger (when movable type is used) Only the robot cable is to be used in a cable track. Housing: PHDR-18VR (JST) Contact : SPHD-001T-P0.5 (JST) Motor-Encoder Integrated Cable for RCA2 \* Enter the cable length (L) into . Compatible to a maximum of 20 meters. Model CB-ACS-MPA (012) <u>eII</u> (23) Min. bend radius r = 84 mm or larger (when movable type is used) Controller side Mechanical side Unit Link Cable for Extension Unit Model CB-REXT-SIO010 ¬xx 7XX



### Controller Connection Cable for Extension Unit

## Model CB-REXT-CTL010

