



Quality and Innovation



Cartesian Robots

ICSA2/ICSPA2

ICSA3/ICSPA3

Contents

■ Cartesian Robot Series Contents	42
■ Features	43
■ Product Types	45
■ Two-Axes Configuration Unit Selection Table	47
■ Three-Axes Configuration Unit Selection Table	49
■ Points to Note	59
■ Explanation of Model Specification Items	61
■ Installation Method	63
■ System Configuration	65

41

ISPA/ICSPA Catalog

Sold & Serviced By:

 **ELECTROMATE**

Toll Free Phone (877) SERV098

Toll Free Fax (877) SERV099

www.electromate.com

sales@electromate.com

Cartesian Robot Series **Contents**

Two-Axes Configuration

X-Y Two-Axes Configuration

ICSA2(ICSPA2)-BK□ H	87
ICSA2(ICSPA2)-BK□ M	89
ICSA2(ICSPA2)-BL□ H	91
ICSA2(ICSPA2)-BL□ M	93
ICSA2(ICSPA2)-BP□ H	95
ICSA2(ICSPA2)-BP□ M	97
ICSA2(ICSPA2)-BQ□ H	99
ICSA2(ICSPA2)-BQ□ M	101

XYB (Y-Axis Base Mount) Type

New Models added!

XYS (Y-Axis Slider Mount) Type

X-Z Two-Axes Configuration

XZ (Z-Axis Base Mount) Type

Y-Z Two-Axes Configuration

YZ (Y-Axis Slider Mount) Type

X-Y Two-Axes Gantry Configuration

XYG (Gantry) Type

Three-Axes Configuration

X-Y Base Mount (XYB) + Z-Axis Configuration

Z-Axis Base Mount Type (Z-Axis Slider Flexible)

ICSA2(ICSPA2)-BA□ H	67
ICSA2(ICSPA2)-BA□ M	69
ICSA2(ICSPA2)-BB□ H	71
ICSA2(ICSPA2)-BB□ M	73
ICSA2(ICSPA2)-BC□ H	75
ICSA2(ICSPA2)-BC□ M	77
ICSA2(ICSPA2)-BD□ H	79
ICSA2(ICSPA2)-BE□ H	81
ICSA2(ICSPA2)-BE□ M	83
ICSA2(ICSPA2)-BF□ H	85
ICSA2(ICSPA2)-SA□ H	103
ICSA2(ICSPA2)-SA□ M	105
ICSA2(ICSPA2)-S1C□ H	107
ICSA2(ICSPA2)-S1C□ M	109
ICSA2(ICSPA2)-S2C□ H	111
ICSA2(ICSPA2)-SG□ H	113
ICSA2(ICSPA2)-ZAH	115
ICSA2(ICSPA2)-ZAM	117
ICSA2(ICSPA2)-Z1CH	119
ICSA2(ICSPA2)-Z1CM	121
ICSA2(ICSPA2)-Z2CH	123
ICSA2(ICSPA2)-ZDH	125
ICSA2(ICSPA2)-ZGH	127
ICSA2(ICSPA2)-ZHH	129
ICSA2(ICSPA2)-YAH	131
ICSA2(ICSPA2)-YAM	133
ICSA2(ICSPA2)-YCH	135
ICSA2(ICSPA2)-YCM	137
ICSA2(ICSPA2)-YGH	139
ICSA2(ICSPA2)-G1JH	141
ICSA2(ICSPA2)-G2JH	143

ICS(P)A3-BA□MB1□	145
ICS(P)A3-BB□HB1□	147
ICS(P)A3-BB□MB1□	149
ICS(P)A3-BB□MB2□	151
ICS(P)A3-BC□HB1□	153
ICS(P)A3-BC□HB2□	155
ICS(P)A3-BC□HB3□	157
ICS(P)A3-BC□MB1□	159
ICS(P)A3-BC□MB2□	161
ICS(P)A3-BC□MB3□	163
ICS(P)A3-BD□HB1□	165
ICS(P)A3-BD□HB2□	167
ICS(P)A3-BD□HB3□	169
ICS(P)A3-BE□HB1□	171
ICS(P)A3-BE□HB2□	173
ICS(P)A3-BE□HB3□	175
ICS(P)A3-BE□MB2□	177
ICS(P)A3-BE□MB3□	179
ICS(P)A3-BF□MB1□	181
ICS(P)A3-BF□HB2□	183
ICS(P)A3-BF□HB3□	185
ICS(P)A3-BA□MS1□	187
ICS(P)A3-BB□HS1□	189
ICS(P)A3-BB□MS1□	191
ICS(P)A3-BC□HS1□	193
ICS(P)A3-BC□HS3□	195
ICS(P)A3-BC□MS1□	197
ICS(P)A3-BC□MS3□	199
ICS(P)A3-BD□HS1□	201
ICS(P)A3-BD□HS3□	203
ICS(P)A3-BE□HS1□	205
ICS(P)A3-BE□HS3□	207
ICS(P)A3-BE□MS1□	209
ICS(P)A3-BE□MS3□	211
ICS(P)A3-BF□HS1□	213
ICS(P)A3-BF□HS3□	215
ICS(P)A3-G1JH81□	217
ICS(P)A3-G1JH82□	219
ICS(P)A3-G1JH83□	221
ICS(P)A3-G2JH81□	223
ICS(P)A3-G2JH82□	225
ICS(P)A3-G2JH83□	227
ICS(P)A3-G1JHS1□	229
ICS(P)A3-G1JHS2□	231
ICS(P)A3-G1JHS3□	233
ICS(P)A3-G2JHS1□	235
ICS(P)A3-G2JHS2□	237
ICS(P)A3-G2JHS3□	239

* In the above model names, □ indicates the configuration direction (1 through 4).

Cartesian Robot Series **Features**

The ICSA/ICSPA Cartesian robots are configuration units based on the two-axes and three-axes configuration patterns that are frequently used. These actuators come pre-wired with brackets attached, so they can be installed in your equipment and used immediately after delivery.

1. Configuration Variations


Fifty-seven standard configuration types are provided, so the user can find the model best suited to existing conditions. We can also build custom configurations not currently represented in the standard range. Please contact us regarding your specifications.

Two-Axes Configuration Type

Two-axes configuration units are available in **31 types**, each combining one of five configuration patterns with different speeds and motor capacities.



① XYB (Y-Axis Base Mount) Type



A basic configuration type where the Y-axis base is mounted to the X-axis bracket.

This actuator operates with a device or Z-axis attached to the Y-axis slider.


Point 1

There are four patterns of Y-axis configuration directions to choose from (refer to the figure shown to right).

Point 2

Select the Y-axis wiring specification from the two options of self-standing cable (standard) and cable track.

■ Configuration Direction



② XYS (Y-Axis Slider Mount) Type



The Y-axis slider is mounted to the X-axis bracket in a manner allowing the Y-axis to move. Use this type when the Y-axis itself must be moved back and forth to avoid an obstacle, etc.


Point 1

There are four patterns of Y-axis configuration directions to choose from (refer to the figure shown to right).


Point 2

Only the self-standing cable option is available for the Y-axis wiring specification.

■ Configuration Direction



③ XZ (Z-Axis Base Mount) Type



The Z-axis (vertical axis) is positioned vertically on the X-axis. Use this type in such applications as inserting loads into a stocker or moving a pallet up and down.

Point 1



Since the Z-axis comes standard with a brake, the slider will not drop even when the power is turned off.

Point 2

The maximum stroke is 2500 mm for the X-axis and 500mm for the Z-axis.

(Consult IAI if you need a longer stroke.)

④ YZ (Y-Axis Slider Mount) Type



The Y-axis is positioned on its side and its slider is connected to the slider of the Z-axis (vertical axis).

Since the Z-axis moves vertically, this type can be fitted with a chuck or other device on the Z-axis for transfer of loads.

Point 1

Since the Z-axis comes standard with a brake, the slider will not drop even when the power is turned off.


Point 2

The standard wiring specification of the Z-axis is the self-standing cable, but the cable track can also be used (custom order).

Point 3

The Z-axis base can be mounted (custom order).

⑤ XYG (Gantry) Type



The Y-axis of the XYG type is placed flat and a support guide is attached at the tip of the Y-axis.

Use this type for transferring heavy objects or when the Y-axis stroke is long and the tip might sag.

Point 1

A maximum of 40 kg can be transferred.

Point 2


The maximum stroke is 2500 mm for the X-axis and 1200 mm for the Y-axis.

(Consult IAI if you need a longer stroke.)

Three-Axes Configuration Type


Three-axes configuration units are available in **102 types**, each combining either the basic XYB (Y-axis base mount) type or high-rigidity XYG (gantry) type with a Z-axis (vertical axis) of high-speed, medium-speed or low-speed specification, providing a maximum load capacity of 19 kg.

Consult IAI for details on three-axes combined types.



Four-Axes Configuration Type


We also offer four-axes configuration types, which are three-axes configuration units with a rotating axis integrated with the Z-axis. Please advise us of your desired conditions, and we will select the best configuration and submit drawings.



Cartesian Robot Series **Product Types****■ Two-Axes Configuration****X-Y Two-Axes Configuration****Y-axis base mount**

The Y-axis slider moves horizontally.

XYB type	BA□H, BA□M	BK□H, BK□M
	BB□H, BB□M	BL□H, BL□M
	BC□H, BC□M	BP□H, BP□M
	BD□H	BQ□H, BP□M
	BE□H, BE□M	
	BF□H	




P67~102

Y-axis slider mount

The entire Y-axis moves horizontally.

XYS type	SA□H, SA□M
	S1C□H, S1C□M
	S2C□H
	SG□H




P103~114

■ Three-Axes Configuration**X-Y Base Mount (XYB)+Z-Axis Configuration****Z-Axis Base Mount Type**

The Z-axis is base mounted to the Y slider.
The Z slider moves vertically.
The Y-axis slider moves horizontally.

BA□MB1□
BB□HB1□
BB□MB1□
BC□HB□□
BC□MB□□
BD□HB□□
BE□HB□□
BE□MB□□
BF□HB□□




P145~186

Z-Axis Slider Mount Type

The Z-axis slider is mounted to the Y-axis slider.
The body of the Z-axis moves vertically.
The Y-axis slider moves horizontally.

BA□MS1□
BB□HS1□
BB□MS□□
BC□HS□□
BC□MS□□
BD□HS□□
BE□HS□□
BE□MS□□
BF□HS□□



P187~216

Z-axis base mount

The Z-axis is positioned vertically and mounted to the X-axis. The Z-axis slider moves vertically.

XZ type

ZAH, ZAM
Z1CH, Z1CM
Z2CH
ZDH
ZGH
ZHH



P115~130

Y-axis slider mount

The Z-axis slider is mounted to the Y-axis positioned on its side. The entire Z-axis moves vertically.

YZ type

YAH, YAM
YCH, YCM
YGH



P131~140

Gantry

A support axis is added in parallel with the X-axis and the Y-axis base is mounted to the sliders on the two axes. The Y-axis slider moves horizontally.

XYG type

G1JH
G2JH




P141~144

■ Four-Axes Configuration**X-Y Gantry (XYG)+Z-Axis Configuration****Z-Axis Base Mount Type**

The Z-axis base mounted to the Y-axis, Z slider moves vertically.
The Y-axis slider moves horizontally.

G1JHB□□
G2JHB□□




P217~228

Z-Axis Slider Mount Type

The Z-axis slider is mounted to the Y-axis slider and moves vertically.
The Y-axis slider moves horizontally.


G1JHS□□
G2JHS□□



P229~240

X-Y Base Mount + Z-Axis + Rotating-Axis Configuration

Rotating-axis mounted to the Z-axis base (Z-slider mounted to Y) of three-axes configuration provides theta motion.




How to Select a Unit (Explanation of the Table)

Start from ① and move toward right as you confirm each condition to select a desired type.

① Select the configuration.

- XYB type** The Y-axis base is mounted to the X-axis.
(The Y-axis slider moves horizontally.)
- XYS type** The Y-axis slider is mounted to the X-axis.
(The Y-axis itself moves horizontally.)
- XZ type** The Z-axis is positioned vertically and mounted to the X-axis.
(The Z-axis slider moves vertically.)
- YZ type** The Z-axis slider is mounted to the Y-axis positioned on its side.
(The Z-axis itself moves vertically.)
- XYG type** A support axis is added in parallel with the X-axis and the Y-axis base is mounted to the sliders on the two axes.
(The Y-axis slider moves horizontally.)



Configuration

XYB type



XYS type



XZ type



YZ type



XYG type



XYG type

- ② Select the line that satisfies both the required Y-axis (Z-axis) stroke and load capacity, and then follow that line to the next column on right.**
(Fields with a “-” indicate that this particular configuration is not supported.)

③ Check the X-axis stroke.

If the condition is not satisfied,
go down to the line below and select a larger type.

④ Select the desired speed.

- ⑤ You have selected the type
that satisfies all your desired conditions.**

Refer to page 43 for the X/Y-axis configuration directions.

Select the X/Y-axis and Z-axis wiring specifications from the following two options:

SC : Self-standing cable
CT : Cable track

* Refer to page 45.

Load capacity (kg)	Y-axis stroke (mm)						
	100	200	300	400	500	600	700
5.2	4.5	3.8	3.1	-	-	-	-
18.2	16.6	12.1	8.1	-	-	-	-
	12.0	11.8	11.1	-	-	-	-
	25.0	21.8	-	-	-	-	-
	20.0	-	18.7	-	-	-	-
28.8	27.8	26.8	21.8	18.7	-	-	-
	20.0	-	18.7	-	-	-	-
-	40.0	-	33.0	27.3	22.9	19.3	-
-	51.2	40.5	33.0	27.3	22.9	19.3	-
-	40.0	-	33.0	27.3	22.9	19.3	-

Load capacity (kg)	Y-axis stroke (mm)						
	100	200	300	400	500	600	700
6.2	5.5	4.8	4.1	-	-	-	-
19.2	14.3	9.3	6.4	-	-	-	-
9.7	8.7	7.7	6.7	5.6	-	-	-
29.7	29.1	19.3	13.6	9.7	-	-	-
29.2	28.2	19.3	13.6	9.7	-	-	-
-	-	20.7	18.2	12.5	8.4	-	-

Load capacity (kg)	Z-axis stroke (mm)						
	100	200	300	400	500	600	700
4.0	3.3	2.6	-	-	-	-	-
10.0	7.5	6.0	-	-	-	-	-
8.5	7.5	6.5	5.5	-	-	-	-
19.0	17.0	14.0	12.0	-	-	-	-
19.0	16.0	13.0	11.0	-	-	-	-
19.0	16.0	13.0	11.0	-	-	-	-
22.0	18.0	16.0	12.0	10.0	-	-	-
22.0	18.0	16.0	12.0	10.0	-	-	-

Load capacity (kg)	Z-axis stroke (mm)						
	100	200	300	400	500	600	700
3.0	2.3	1.6	-	-	-	-	-
11.0	10.3	9.6	-	-	-	-	-
11.9	10.9	9.9	8.9	-	-	-	-
13.1	12.1	11.1	10.1	-	-	-	-
27.0	25.5	23.9	22.3	20.7	-	-	-

Load capacity (kg)	Y-axis stroke (mm)						
	500 ~ 700			800 ~ 1200			
	40.0	-	-	40.0	-	-	-
-	-	-	-	40.0	-	-	-

Refer to page 43 for the X/Y-axis configuration directions.

Select the X/Y-axis and Z-axis wiring specifications from the following two options:

SC : Self-standing cable
CT : Cable track

* Refer to page 45.



Caution

The maximum speed of some long-stroke types (indicated by *) has been reduced to prevent the ball screw from reaching a dangerous speed once the desired type has been selected. Check the actual speed specification on the page corresponding to the selected type.

(3)

(4)

(5) Applicable type

X-axis stroke (mm)	Maximum speed (X-axis/Y-axis) (mm/sec)
100 ~ 600	800/800
100 ~ 600	400/400
200 ~ 800	*1000/800
200 ~ 800	*500/400
200 ~ 800	*1000/1000
200 ~ 800	*500/500
800 ~ 2000	*1000/1000
300 ~ 1000	*1000/1000
300 ~ 1000	*500/500
1000 ~ 2500	*1000/1000

Configuration type

Page

BA□ H
BA□ M
BB□ H
BB□ M
BC□ H
BC□ M
BD□ H
BE□ H
BE□ M
BF□ H

X-axis stroke (mm)	Maximum speed (X-axis/Y-axis) (mm/sec)
100 ~ 600	800/800
100 ~ 600	400/400
200 ~ 800	*1000/1000
200 ~ 800	*500/500
200 ~ 800	*1000/1000
300 ~ 800	1000/1000

Configuration type
SA□ H
SA□ M
S1C□ H
S1C□ M
S2C□ H
SG□ H

X-axis stroke (mm)	Maximum speed (X-axis/Z-axis) (mm/sec)
100 ~ 600	800/400
100 ~ 600	400/200
200 ~ 800	*1000/500
200 ~ 800	*500/250
200 ~ 800	*1000/500
800 ~ 2000	*1000/500
200 ~ 800	1000/500
1000 ~ 2500	*1000/500

Configuration type
ZAH
ZAM
Z1CH
Z1CM
Z2CH
ZDH
ZGH
ZHH

Y-axis stroke (mm)	Maximum speed (Y-axis/Z-axis) (mm/sec)
100 ~ 400	800/400
100 ~ 400	400/200
200 ~ 700	1000/500
200 ~ 700	*500/250
200 ~ 700	1000/500


Configuration type
YAH
YAM
YCH
YCM
YGH

X-axis stroke (mm)	Maximum speed (X-axis/Y-axis) (mm/sec)
1000 ~ 2500	*1000/1000
1000 ~ 2500	*1000/1000

Configuration type
G1JH
G2JH

Cartesian Robots Series Three-Axes Configuration Unit Selection Table

How to Select a Unit (Explanation of the Table) Start from ① and move toward right as you confirm each condition to select a desired type.



Refer to page 45 for the X/Y-Axis configuration directions.

Select the X/Y-Axis and Z-Axis wiring specifications from the two options to the right.

Only cable track is available for X/Y-Axis type D, F, 1J, and 2J.

Only Self-standing cable is available for Z-Axis Slider Mount Type.

We can also build custom configurations not currently represented in the standard range.

Please contact us regarding your specifications.

SC: Self-standing cable
CT: Cable track

* Refer to page 241.

[Z-Axis Base Mount] ①

Z-Axis Speed Type	Z-Axis			Y-Axis Stroke (mm)										
	Load Capacity	Stroke (mm)			100	200	300	400	500	600	700	800~1200		
High-Speed Type 800~1000 mm/sec	3kg or less	100~300		Load Capacity (kg)	3.0			-	-	-	-	-		
		100~400			3.0			-	-	-	-	-		
		100~500			-	3.0			-					
		100~600			-	-	-	-	3.0			-		
		100~600			-	-	-	-	-	-	-	3.0		
	9kg or less	100		Load Capacity (kg)	9.0			-	-	-	-	-		
		200			-	9.0			-			-		
		300			-	9.0			-			-		
		400			-	8.6			7.3	-	-	-		
		500			-	7.6			6.3	-	-	-		
		1000~600			-	9.0			-			6.9		
					-	-	-	-	9.0			-		
					-	-	-	-	-	-	-	9.0		

Example of Selection

Conditions

The Z-Axis is subject to base mount.
 Allowable tip load : 2kg
 Speed : 800mm/sec or more
 Z-Axis Stroke : 200mm
 Y-Axis Stroke : 500mm
 X-Axis Stroke : 700MM

- ① Select the chart of [Z-Axis Base Mount Type].
- ② Select "High-speed" type since the desired speed is 800mm/sec."
- ③ Select "3kg or less" since the load capacity is 2kg."
- ④ Move the line for 100~300 to the right since Z-Axis stroke is 200mm.
- ⑤ The crossed column for Z-Axis stroke 100~300mm and Y-Axis stroke 500mm reads "---" (Not applicable), so apply the line below. Since the Y-Axis stroke on the line covers 500mm, shift to the right."
- ⑥ The X-Axis stroke is applicable up to 800mm, so shift to the right."
- ⑦ The maximum speed for X-Axis/ Y Axis is 1000mm/sec and satisfy the condition. Shift to the right.
- ⑧ As a result, Unit Type [BC□HB1H] is the selected suitable model."

Note The numbers in () in X-Axis stroke in the chart below are for models in () listed in Applicable Type's configuration type.
 Example: If the X-Axis stroke in the above example is 1000mm, configuration Applicable Type will be [BD□HB1H].

⑥ *() is for the type BD□HB□□ or BF□HB□□.

⑦

⑧ Applicable Type

	X-Axis Stroke (mm)	Maximum Speed (X-axis / Y-axis) (mm/sec)		Configuration Type	Page
→	200~800	1000/800	→	ICSA [ICSPA] 3-BB□HB1H	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BC□HB1H (BD□HB1H)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB1H (BF□HB1H)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G1JHB1H	
		1000/1000		ICSA [ICSPA] 3-G2JHB1H	
→	200~800 (800~2000)	1000/1000	→	ICSA [ICSPA] 3-BC□HB3H (BD□HB3H)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB3H (BF□HB3H)	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BC□HB3H (BD□HB3H)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB3H (BF□HB3H)	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BC□HB3H (BD□HB3H)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB3H (BF□HB3H)	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BC□HB3H (BD□HB3H)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB3H (BF□HB3H)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB3H (BF□HB3H)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G1JHB3H	

[Z-Axis Base Mount] ①

②

③

④

⑤

Z-Axis Speed Type	Z-Axis			Y-Axis Stroke (mm)												
	Load Capacity	Stroke (mm)			100	200	300	400	500	600	700	800~1200				
Mid-Speed Type 400~500 mm/sec	6kg or less	100		Load Capacity (kg)	6.0	2.9	-	-	-	-	-	-				
					6.0	5.9	-	-	-	-	-	-				
					6.0	-	-	-	-	-	-	-				
		200			6.0	2.3	-	-	-	-	-	-				
					6.0	5.3	-	-	-	-	-	-				
					6.0	-	-	-	-	-	-	-				
		300			6.0	1.7	-	-	-	-	-	-				
					5.6	4.7	-	-	-	-	-	-				
					6.0	-	-	-	-	-	-	-				
	100~400	100~500			6.0	-	-	-	-	-	-	-				
					6.0	-	-	-	-	-	-	-				
					6.0	-	-	-	-	-	-	-				
					-	6.0	-	-	-	-	-	-				
					-	-	6.0	-	-	-	-	-				
High-Speed Type 500~600 mm/sec	9kg or less	100		Load Capacity (kg)	9.0	-	-	-	-	-	-	-				
					9.0	-	-	-	-	-	-	-				
					9.0	-	-	-	-	-	-	-				
		200			9.0	8.4	-	-	-	-	-	-				
					9.0	-	-	-	-	-	-	-				
					8.6	7.3	-	-	-	-	-	-				
		300			9.0	-	-	-	-	-	-	-				
					7.6	6.3	-	-	-	-	-	-				
					9.0	-	-	-	-	-	-	-				
	400	500			9.0	-	-	-	-	-	-	-				
					9.0	-	-	-	-	-	-	-				
					-	-	-	-	-	-	-	-				
					-	-	-	-	-	-	-	-				
					-	-	-	-	-	-	-	-				
Super-High-Speed Type 600~700 mm/sec	100~600	100		Load Capacity (kg)	10.7	-	-	-	-	-	-	-				
					19.0	18.5	17.5	12.5	9.4	-	-	-				
					-	19.0	-	-	18.0	13.6	10.0	-				
		200			-	-	-	-	-	-	-	-				
					-	-	-	-	-	-	-	-				
					-	-	-	-	-	-	-	-				
		300			9.7	-	-	-	8.4	-	-	-				
					18.5	17.5	16.5	11.5	8.4	-	-	-				
					-	19.0	-	-	17.0	12.6	9.0	-				
	500	600			-	-	-	-	-	-	-	-				
					-	-	-	-	-	-	-	-				
					-	-	-	-	-	-	-	-				
					-	-	-	-	-	-	-	-				
					-	-	-	-	-	-	-	-				

6 *() is for the type BD□HB□□ or BF□HB□□.

7

8 Applicable Type

	X-Axis Stroke (mm)	Maximum Speed (X-axis / Y-axis) (mm/sec)		Configuration Type	Page
	100~600	400/400		ICSA [ICSPA] 3-BA□MB1M	
	200~800	1000/800		ICSA [ICSPA] 3-BB□HB1M	
	200~800	500/400		ICSA [ICSPA] 3-BB□MB1M	
	100~600	400/400		ICSA [ICSPA] 3-BA□MB1M	
	200~800	1000/800		ICSA [ICSPA] 3-BB□HB1M	
	200~800	500/400		ICSA [ICSPA] 3-BB□MB1M	
	100~600	400/400		ICSA [ICSPA] 3-BA□MB1M	
	200~800	1000/800		ICSA [ICSPA] 3-BB□HB1M	
	200~800	500/400		ICSA [ICSPA] 3-BB□MB1M	
	300~1000	1000/1000		ICSA [ICSPA] 3-BC□HB1M (BD□HB1M)	
	300~1000	1000/1000		ICSA [ICSPA] 3-BE□HB1M (BF□HB1M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G1JHB1M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G2JHB1M	
	200~800	500/400		ICSA [ICSPA] 3-BB□MB2M	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BC□HB2M (BD□HB2M)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB2M (BF□HB2M)	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BC□HB2M (BD□HB2M)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB2M (BF□HB2M)	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BC□HB2M (BD□HB2M)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB2M (BF□HB2M)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB2M (BF□HB2M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G1JHB2M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G2JHB2M	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BC□HB3M (BD□HB3M)	
	200~800	500/500		ICSA [ICSPA] 3-BC□MB3M	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB3M (BF□HB3M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G1JHB3M	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-G2JHB3M	
	200~800	50/500		ICSA [ICSPA] 3-BC□HB3M (BD□HB3M)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB3M (BF□HB3M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G1JHB3M	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-G2JHB3M	
	200~800	500/500		ICSA [ICSPA] 3-BC□MB3M	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB3M (BF□HB3M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G1JHB3M	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-G2JHB3M	
	200~800	500/500		ICSA [ICSPA] 3-BC□MB3M	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HB3M (BF□HB3M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G1JHB3M	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-G2JHB3M	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BC□HB3M (BD□HB3M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BE□HB3M (BF□HB3M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G1JHB3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G2JHB3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BC□HB3M (BD□HB3M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BE□HB3M (BF□HB3M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G1JHB3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G2JHB3M	

[Z-Axis Base Mount] ①

②

③

④

⑤

Z-Axis Speed Type	Z-Axis			Y-Axis Stroke (mm)									
	Load Capacity	Stroke (mm)		100	200	300	400	500	600	700	800~1200		
14kg or less	Low-Speed Type 200~250 mm/sec	100		13.0	11.4	6.9	2.9	—	—	—	—		
				7.1	6.9	6.2	—	—	—	—	—		
				14.0	—	—	—	—	—	—	—		
				14.0	—	13.5	—	—	—	—	—		
				—	14.0	—	—	—	—	—	—		
		200		12.4	10.8	6.3	2.3	—	—	—	—		
				6.1	5.9	5.2	—	—	—	—	—		
				14.0	—	—	—	—	—	—	—		
				14.0	—	12.9	—	—	—	—	—		
				—	14.0	—	13.5	—	—	—	—		
19kg or less	Low-Speed Type 200~250 mm/sec	300		11.8	10.2	5.7	1.7	—	—	—	—		
				5.6	5.4	4.7	—	—	—	—	—		
				14.0	—	—	—	—	—	—	—		
				14.0	—	12.3	—	—	—	—	—		
				—	14.0	—	12.9	—	—	—	—		
		400		13.5	—	11.7	—	—	—	—	—		
				—	14.0	—	12.3	—	—	—	—		
				—	14.0	—	11.7	—	—	—	—		
				—	—	—	—	—	—	—	—		
				—	—	—	—	—	—	—	14.0		
100~600	Low-Speed Type 200~250 mm/sec	100		15.9	—	12.7	—	—	—	—	—		
				10.7	—	9.4	—	—	—	—	—		
				19.0	18.5	17.5	12.5	9.4	—	—	—		
				—	19.0	—	18.0	13.6	10.0	—	—		
				—	—	—	—	—	19.0	—	—		
		200		14.6	—	11.4	—	—	—	—	—		
				9.7	—	8.4	—	—	—	—	—		
				18.5	17.5	16.5	11.5	8.4	—	—	—		
				—	19.0	—	17.0	12.6	9.0	—	—		
				—	—	—	—	—	19.0	—	—		
100~600	Low-Speed Type 200~250 mm/sec	300		13.8	—	10.6	—	—	—	—	—		
				8.6	—	7.3	—	—	—	—	—		
				17.4	16.4	15.4	10.4	7.3	—	—	—		
				—	19.0	—	15.9	11.5	7.9	—	—		
				—	—	—	—	—	19.0	—	—		
		400		12.8	—	9.6	—	—	—	—	—		
				7.6	—	6.3	—	—	—	—	—		
				16.4	15.4	14.4	9.4	6.3	—	—	—		
				—	19.0	—	14.9	10.5	6.9	—	—		
				—	—	—	—	—	18.7	—	—		
100~600	Low-Speed Type 200~250 mm/sec	500		19.0	—	13.8	9.4	5.8	—	—	—		
				—	—	—	—	—	17.6	—	—		
		100~600		—	—	—	—	—	16.6	—	—		
				—	—	—	—	—	—	—	16.6		

6 * () is for the type BD□HB□□ or BF□HB□□.

7

[Z-Axis Slider Mount] ①

②

③

④

⑤

Z-Axis Speed Type	Z-Axis			Y-Axis Stroke (mm)										
	Load Capacity	Stroke (mm)			100	200	300	400	500	600	700	800~1200		
Mid-Speed Type 400~500 mm/sec	3kg or less	100	Load Capacity (kg)	3.0	-	-	-	-	-	-	-	-		
				3.0	-	-	-	-	-	-	-	-		
				3.0	-	-	-	-	-	-	-	-		
				3.0	3.0	-	-	-	-	-	-	-		
				-	-	-	-	-	-	-	-	-		
		200		-	-	-	-	-	-	-	-	-		
				3.0	3.0	-	-	-	-	-	-	-		
				-	-	-	-	-	-	-	-	3.0		
				2.3	-	-	-	-	-	-	-	-		
				2.3	-	-	-	-	-	-	-	-		
		300		2.3	-	-	-	-	-	-	-	-		
				-	-	-	-	-	-	-	-	-		
				2.3	2.3	-	-	-	-	-	-	-		
				-	-	-	-	-	-	-	-	-		
				1.6	-	-	-	-	-	-	-	-		
		400		1.6	-	-	-	-	-	-	-	-		
				1.6	-	-	-	-	-	-	-	-		
				-	-	-	-	-	-	-	-	-		
				1.6	1.6	-	-	-	-	-	-	-		
				-	-	-	-	-	-	-	-	-		
12kg or less	12kg or less	100	Load Capacity (kg)	10.0	8.7	-	-	-	-	-	-	-		
				-	11.9	-	-	-	-	-	-	-		
				-	-	-	-	-	-	-	-	11.9		
				9.0	7.7	-	-	-	-	-	-	-		
				-	10.9	-	-	-	-	-	-	-		
		200		-	-	-	-	-	-	-	-	-		
				10.9	10.9	-	-	-	-	-	-	-		
				-	-	-	-	-	-	-	-	-		
				8.0	6.7	-	-	-	-	-	-	-		
				-	9.9	-	-	-	-	-	-	-		
		300		9.9	9.9	-	-	-	-	-	-	-		
				-	-	-	-	-	-	-	-	-		
				8.9	8.9	-	-	-	-	-	-	-		
				-	-	-	-	-	-	-	-	-		
				8.9	8.9	-	-	-	-	-	-	-		
		400		-	-	-	-	-	-	-	-	-		
				7.8	7.8	-	-	-	-	-	-	-		
				-	-	-	-	-	-	-	-	-		
				19.0	19.0	-	-	-	-	-	-	-		
				-	7.8	-	-	-	-	-	-	-		

6 *() is for the type BD□HB□□ or BF□HB□□.

7

8 Applicable Type

	X-Axis Stroke (mm)	Maximum Speed (X-axis / Y-axis) (mm/sec)		Configuration Type	Page
	100~600	400/400		ICSA [ICSPA] 3-BA□MS1M	
	200~800	1000/800		ICSA [ICSPA] 3-BB□HS1M	
	200~800	500/500		ICSA [ICSPA] 3-BB□MS1M	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BC□HS1M (BD□HS1M)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BE□HS1M (BF□HS1M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G1JHS1M	
	100~600	400/400		ICSA [ICSPA] 3-G2JHS1M	
	200~800	1000/800		ICSA [ICSPA] 3-BA□MS1M	
	200~800	500/500		ICSA [ICSPA] 3-BB□HS1M	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BB□MS1M	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BC□HS1M (BD□HS1M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BE□HS1M (BF□HS1M)	
	100~600	400/400		ICSA [ICSPA] 3-G1JHS1M	
	200~800	1000/800		ICSA [ICSPA] 3-G2JHS1M	
	200~800	500/500		ICSA [ICSPA] 3-BA□MS1M	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BB□HS1M	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BC□HS1M (BD□HS1M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BE□HS1M (BF□HS1M)	
	100~600	400/400		ICSA [ICSPA] 3-G1JHS1M	
	200~800	1000/800		ICSA [ICSPA] 3-G2JHS1M	
	200~800	500/500		ICSA [ICSPA] 3-BA□MS1M	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BB□HS1M	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BC□HS1M (BD□HS1M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BE□HS1M (BF□HS1M)	
	100~600	400/400		ICSA [ICSPA] 3-G1JHS1M	
	200~800	1000/800		ICSA [ICSPA] 3-G2JHS1M	
	200~800	500/500		ICSA [ICSPA] 3-BA□MS1M	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BB□HS1M	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BC□HS1M (BD□HS1M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BE□HS1M (BF□HS1M)	
	100~600	400/400		ICSA [ICSPA] 3-G1JHS1M	
	200~800	1000/800		ICSA [ICSPA] 3-G2JHS1M	
	200~800	500/500		ICSA [ICSPA] 3-BA□MS1M	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BB□HS1M	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-BC□HS1M (BD□HS1M)	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BE□HS1M (BF□HS1M)	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-G1JHS3M	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-G2JHS3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BC□HS3M (BD□HS3M)	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BE□HS3M (BF□HS3M)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-G1JHS3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G2JHS3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BC□HS3M (BD□HS3M)	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BE□HS3M (BF□HS3M)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-G1JHS3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G2JHS3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BC□HS3M (BD□HS3M)	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BE□HS3M (BF□HS3M)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-G1JHS3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G2JHS3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BC□HS3M (BD□HS3M)	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BE□HS3M (BF□HS3M)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-G1JHS3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G2JHS3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-BC□HS3M (BD□HS3M)	
	200~800 (800~2000)	1000/1000		ICSA [ICSPA] 3-BE□HS3M (BF□HS3M)	
	300~1000 (1000~2500)	1000/1000		ICSA [ICSPA] 3-G1JHS3M	
	1000~2500	1000/1000		ICSA [ICSPA] 3-G2JHS3M	

[Z-Axis Slider Mount] ①

②

③

④

⑤

Z-Axis Speed Type	Z-Axis			Y-Axis Stroke (mm)									
	Load Capacity	Stroke (mm)		100	200	300	400	500	600	700	800~1200		
Low-Speed Type 400~500 mm/sec	11 kg or less	100		11.0	7.6	3.6	—	—	—	—	—		
				7.2	7.0	6.3	—	—	—	—	—		
				11.0	—	—	—	—	—	—	—		
				11.0	—	—	—	—	—	—	—		
		200		—	11.0						—		
				—	—	—	—	11.0	—	—	—		
				—	—	—	—	—	—	—	11.0		
				10.3	6.9	2.9	—	—	—	—	—		
		300		6.5	6.3	5.6	—	—	—	—	—		
				10.3	—	—	—	—	—	—	—		
				10.3	—	—	—	—	—	—	—		
				—	10.3						—		
		400		—	—	—	—	10.3	—	—	—		
				—	—	—	—	—	—	—	10.3		
				9.6	6.2	2.2	—	—	—	—	—		
				5.8	5.6	4.9	—	—	—	—	—		
				9.6	—	—	—	—	—	—	—		
				9.6	—	—	—	—	—	—	—		
				—	9.6						—		
				—	—	—	—	9.6	—	—	—		
				—	8.9						—		
				—	—	—	—	8.9	—	—	—		
				—	—	—	—	—	—	—	8.9		
				—	—	—	—	—	—	—	8.9		

6

*() is for the type BD□HB□□ or BF□HB□□.

7**8**

Applicable Type

	X-Axis Stroke (mm)		Maximum Speed (X-axis / Y-axis) (mm/sec)		Configuration Type	Page
	100~600		400~400		ICSA [ICSPA] 3-BA□MS1L	
	200~800		1000~800		ICSA [ICSPA] 3-BB□HS1L	
	200~800		500~400		ICSA [ICSPA] 3-BB□MS1L	
	200~800 (800~2000)		1000~1000		ICSA [ICSPA] 3-BC□HS1L (BD□HS1L)	
	300~1000 (1000~2500)		1000~1000		ICSA [ICSPA] 3-BE□HS1L (BF□HS1L)	
	1000~2500		1000~1000		ICSA [ICSPA] 3-G1JHS1L	
	100~600		400~400		ICSA [ICSPA] 3-G2JHS1L	
	200~800		1000~800		ICSA [ICSPA] 3-BA□MS1L	
	200~800		500~400		ICSA [ICSPA] 3-BB□HS1L	
	200~800 (800~2000)		1000~1000		ICSA [ICSPA] 3-BB□MS1L	
	300~1000 (1000~2500)		1000~1000		ICSA [ICSPA] 3-BC□HS1L (BD□HS1L)	
	1000~2500		1000~1000		ICSA [ICSPA] 3-BE□HS1L (BF□HS1L)	
	100~600		400~400		ICSA [ICSPA] 3-G1JHS1L	
	200~800		1000~800		ICSA [ICSPA] 3-G2JHS1L	
	200~800		500~400		ICSA [ICSPA] 3-BA□MS1L	
	200~800 (800~2000)		1000~1000		ICSA [ICSPA] 3-BB□HS1L	
	300~1000 (1000~2500)		1000~1000		ICSA [ICSPA] 3-BB□MS1L	
	1000~2500		1000~1000		ICSA [ICSPA] 3-BC□HS1L (BD□HS1L)	
	300~1000 (1000~2500)		1000~1000		ICSA [ICSPA] 3-BE□HS1L (BF□HS1L)	
	1000~2500		1000~1000		ICSA [ICSPA] 3-G1JHS1L	



X-Y Two-Axes Configuration

ICSA2(ICSPA2)-BK□ H	87
ICSA2(ICSPA2)-BK□ M	89
ICSA2(ICSPA2)-BL□ H	91
ICSA2(ICSPA2)-BL□ M	93
ICSA2(ICSPA2)-BP□ H	95
ICSA2(ICSPA2)-BP□ M	97
ICSA2(ICSPA2)-BQ□ H	99
ICSA2(ICSPA2)-BQ□ M	101

Check out
the New Models!

Notes on Catalog Specifications**Speed**

"Speed" refers to the specified speed at which the actuator slider will move.

The slider accelerates from a stationary state, and once the specified speed is reached it will maintain that speed until the specified position (immediately before the target position), where it will begin decelerating to stop at the target position.

< Caution >

- ① With all Cartesian robot models, the maximum speed will not change even when the load placed on the slider is changed.
- ② The time needed to reach the specified speed will vary according to the acceleration (deceleration).
- ③ If the travel distance is short, the specified speed may not be reached.
- ④ With a long-stroke axis, the maximum speed will drop to avoid reaching a dangerous speed.
(If you are using a 600 or longer stroke, check the maximum speed for the applicable stroke.)
- ⑤ When calculating the travel time, consider acceleration, deceleration and stabilization periods in addition to the travel time at the specified speed. (Refer to pages 39 and 40 for the method to calculate travel time.)
- ⑥ Speed can be set in increments of 1 mm/sec in a program.

Acceleration/Deceleration

"Acceleration" refers to the rate of change of speed when the speed rises from zero (stationary state) to the specified speed.

"Deceleration" refers to the rate of change of speed when the specified speed drops to zero (stationary state).

< Caution >

- ① Increasing the acceleration (deceleration) will shorten the duration the actuator accelerates (decelerates) and decrease the travel time. However, doing so will also cause rapid acceleration (deceleration), resulting in increased shock.
- ② The load capacity of each type assumes operation at the rated acceleration and maximum speed.
(The rated acceleration is 0.3 G for the standard type and 0.15 G when the lead is 4 or 5 mm.)
- ③ The ICSA2/ICSPA2 supports a maximum acceleration of 1.0 G.
The load capacity will decrease when the specified acceleration is increased beyond the rated acceleration.
For the load capacity at a raised acceleration, refer to the table of load capacity by acceleration corresponding to each actuator type.
- ④ Acceleration can be set (specified) in increments of 0.01 G for each position movement in a program.

Positioning Repeatability

"Positioning repeatability" refers to the positioning accuracy of repeated movements to a pre-stored position.

This is not the same as "absolute positioning accuracy," so exercise caution.

Home

The home is set on the motor side for the standard specification, or on the counter-motor side for the reversed-home specification.

< Caution >

- The incremental actuator always requires homing every time the power is reconnected. (Homing is not required for the absolute type even after reconnecting the power.)
- During homing the slider (or rod or arm) will move to the mechanical end before reversing, so be careful to prevent contact with surrounding parts.
- Note that changing the home position from the standard to reverse homing specification will require the actuator to be returned to IAI for adjustment.

Duty

IAI recommends that our actuators be used at a duty of 50% or less as a guideline in view of the relationship of service life and accuracy.

$$\text{Duty (\%)} = \frac{\text{Acceleration / Deceleration Time}}{\text{Motion time} + \text{Inactivity}} \times 100$$


Options

If the creep sensor (C) or home limit switch (L) is specified, a sensor cover will be provided on the side face of each axis.

Therefore, be careful to prevent contact between each cover and peripheral equipment.

As a rule, a sensor cover is installed on the inside of the X-axis (Y-axis overhung direction), or the top side of the Y-axis. The installation position on the Z-axis will vary depending on the configuration pattern.

With a single-axis robot, the option codes will change when the sensor installation position is reversed (opposite side specification). With a Cartesian robot, however, the option codes need not be changed (only C and L are available).



[ICSA2/ICSPA2]

* In the standard specification the creep sensor (C) and home limit switch (L) are installed on the right side as viewed from the motor.

Configuration type	Configuration direction	X-axis installation side	Y-axis installation side	Z-axis installation side
XYB	1	Opposite side	Opposite side	—
	2	Standard	Standard	—
	3	Opposite side	Standard	—
	4	Standard	Opposite side	—
XYS	1	Opposite side	Standard	—
	2	Standard	Opposite side	—
	3	Opposite side	Opposite side	—
	4	Standard	Standard	—
XZ		Opposite side	—	Opposite side
YZ		—	Standard	Opposite side
XYG		Opposite side	Opposite side	—

Cartesian Robot Series **Explanation of Model Specification Items**

Cartesian robot series features two-axes and three-axes.

Refer to the right page for the explanation of each model specification item.

The selection range for each item will vary depending on the actuator type. For details, refer to the page corresponding to each actuator type.

Number of axes	(1) Series	(2) Type	Encoder type	(4)		(5)		(6)		(7) Applicable controller	(8) Cable length	(9) Cable management between axis 1 and 2	(10) Cable management between axis 2 and 3				
				Axis 1 (X-axis, Z-axis)		Axis 2 (X-axis, Z-axis)		Axis 3 (Z-axis)									
				Stroke (cm)	Options	Stroke (cm)	Options	Stroke (cm)	Options								
2 axes	ICSA2 ICSPA2	BA□H BK□H BA□M BK□M BB□H BL□H BB□M BL□M BC□H BP□H BC□M BP□M BD□H BQ□H BE□H BQ□H BE□M BF□H SA□H SA□M S1C□H S1C□M SA□M S2C□H SG□M ZAH ZAM Z1CH Z1CM Z2CH ZDH ZGH ZHH YAH YAM YCH YCM YGH G1JH G2JH	-	-	10 ~ 250	AQ B C L NM RT	10 ~ 120	AQ B C L NM RT	-	-	-	CT SC	-				
3 axes	ICSA3 ICSPA3	BB□MB□O BC□HB□O BC□MB□O BD□HB□O BE□HB□O BE□MB□O BF□HB□O G1JH□O G2JH□O BA□MS1□ BB□HS1□ BB□MS1□ BC□HS□O BC□MS□O BD□HS□O BE□HS□O BE□MS□O BF□HS□O G1JHS□O G2JHS□O	-	-	10 ~ 250	AQ B C L NM RT	10 ~ 120	AQ B C L NM RT	10 ~ 60	AQ B C L NM RT	-	T1 □ L (Custom order)	CT-CT SC-SC (CT-SC)				

* In the above model names, □ indicates the configuration direction (1 through 4) (refer to page 43).

(1) Series

Indicate the name of each series.

- ICSA2: ISA Two-axes configuration
- ICSPA2: ISPA Two-axes configuration
- ICSA3: ISA Three-axes configuration
- ICSPA3: ISPA Three-axes configuration

(2) Type

Indicate the configuration pattern, configuration direction, configuration model and speed type.

Two-Axes Configuration	$\frac{B}{(1)}$	$\frac{B}{(2)}$	$\frac{1}{(3)}$	$\frac{H}{(4)}$	Three-Axes Configuration	$\frac{B}{(1)}$	$\frac{B}{(2)}$	$\frac{1}{(3)}$	$\frac{H}{(4)}$	$\frac{B}{(5)}$	$\frac{1}{(6)}$	$\frac{M}{(7)}$
------------------------	-----------------	-----------------	-----------------	-----------------	--------------------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------

- | | |
|---|--|
| (1) XY-axis configuration / component type (*1) | B:XYB Type / S: XYS Type / Z: XZ Type / Y: YZ Type / G: XYG Type |
| (2) XY-axis configuration / size type | A / B / C / 1C / 2C / D / E / F / G / 1J / 2J |
| (3) XY-axis configuration direction (*2) | 1 / 2 / 3 / 4 |
| (4) XY-axis speed type | H: High-speed type / M: Mid-speed type |
| (5) Z-axis installation type | B: Base mounted / S: Slider mounted |
| (6) Z-axis motor output | 1: 60W / 2: 100W / 3: 200W |
| (7) Z-axis speed type | H: High-speed type / M: Mid-speed type / L: Low-speed type |

(*1) B(XYB type) and G(XYG type) are available for three-axes configuration.

(*2) Specify only when XY-axis configuration type is B(XYB type) or S(XYS type).

(3) Encoder type

Indicate whether the encoder installed in the actuator is an “absolute type” or “incremental type.”

A: Absolute type

Since the current slider position will be retained after the power is turned off, homing is not required when the actuator is powered up.

I: Incremental type

Since the slider position data are cleared when the power is turned off, homing must be performed every time the actuator is powered up.

(4) Axis 1 details

Indicate the stroke of axis 1 of the two-axes configuration type, as well as an option(s) to be equipped on that axis.

Enter the stroke in centimeters (e.g., 500-mm stroke → 50).

When selecting multiple options, specify them in alphabetical order without a hyphen in between (e.g., AQ seal + Creep sensor + Limit switch + Reversed home specification → AQCLNM).

* Refer to the explanation of single-axis robot models (page 13) for the details of options.

(5) Axis 2 details

Indicate the stroke of axis 2 of the two-axes configuration type, as well as an option(s) to be equipped on that axis. Other details are the same as above.

(6) Axis 3 details

Indicate the stroke of axis 3 of the three-axes configuration type, as well as an option(s) to be equipped on that axis. Other details are the same as above.

(7) Applicable controller

Indicate the type of controller to be used with the actuator.

T1: XSEL-J/K, E-Con, P-Driver

T2: XSEL-P/Q

(8) Cable length

Indicate the length of the motor/encoder cable connecting the actuator to the controller.

Two standard lengths of 3L (3 m) and 5L (5 m) are available. You can also specify a different length as a custom order.

(Maximum length is 20m)

(9) Cable management between axis 1 and 2

Indicate the cable management between axis 1 and 2.

SC: Self-standing cable

CT: Cable track

* The cable management between axis 1 and 2 for types below are available in cable track (CT).

BD□H, BF□H, BD□HB□□, BF□HB□□,
G1JHB□□, G2JHB□□, BD□HS□□,
BF□HS□□, G1JHS□□, G2JHS□□

(10) Cable management between axis 2 and 3

Indicate the cable management from axis 2 to axis 3.

SC: Self-standing cable

CT: Cable track


* The cable management between axis 2 and 3 is basically the same as that between axis 1 and 2 except the types listed to the left.

Cartesian Robots Installation Method ICSA2/ICSPA2/ICSA3/ICSPA3

Two-Axes Configuration


X-Y-B type

- Affix the actuators using the through holes provided on the bottom surface of the X-axis.
- BA□H, BA□M : ø7 (P15 ISA-SXM Refer to the bottom plan view.)
- BB□H, BB□M : ø9 (P18 ISA-MXM Refer to the bottom plan view.)
- BC□H, BC□M : ø9 (P19 ISA-MXM Refer to the bottom plan view.)
- BD□H, : ø9 (P20 ISA-MXMX Refer to the bottom plan view.)
- BE□H, BE□M : ø9 (P26 ISA-LXM Refer to the bottom plan view.)
- BF□H, : ø9 (P28 ISA-LXMX Refer to the bottom plan view.)
- BK□H, BK□M
- BL□H, BL□M
- BP□H, BP□M
- BQ□H, BQ□M




X-Y-S type

- Affix the actuators using the through holes provided on the bottom surface of the X-axis.
- SA□H, SA□M : ø7 (P15 ISA-SXM Refer to the bottom plan view.)
- S1C□H, S1C□M: ø9 (P18 ISA-MXM Refer to the bottom plan view.)
- S2C□H : ø9 (P19 ISA-MXMX Refer to the bottom plan view.)




X-Z type

- Affix the actuators using the through holes provided on the bottom surface of the X-axis.
- ZAH, ZAM : ø7 (P15 ISA-SXM Refer to the bottom plan view.)
- Z1CH, Z1CM: ø9 (P18 ISA-MXM Refer to the bottom plan view.)
- Z2CH : ø9 (P19 ISA-MXM Refer to the bottom plan view.)
- ZDH, : ø9 (P20 ISA-MXMX Refer to the bottom plan view.)
- ZGH : ø9 (P26 ISA-LXM Refer to the bottom plan view.)
- ZHH : ø9 (P28 ISA-LXMX Refer to the bottom plan view.)




Y-Z type

- Affix the actuators using the threaded holes provided on the bottom surface of the actuator.
- YAH, YAM : M6 (P16 ISA-SYM Refer to the bottom plan view.)
- YCH, YCM : M8 (P22 ISA-MYM Refer to the bottom plan view.)
- YGH : M8 (P32 ISA-LYM Refer to the bottom plan view.)



X-Y-G type


- Affix the actuators using the through holes provided on the bottom surface of the X-axis (driving shaft / driven shaft).
- G1JH (Driving shaft) : ø9 (P30 ISA-LXUWX Refer to the bottom plan view.)
(Driven shaft) : ø7 (P15 ISA-SXM Refer to the bottom plan view.)
- G2JH (Driving shaft) : ø9 (P30 ISA-LXUWX Refer to the bottom plan view.)
(Driven shaft) : ø7 (P15 ISA-SXM Refer to the bottom plan view.)



Three-Axes Configuration

XYB+Z Axis type


- Affix the actuators using the through holes provided on the bottom surface of the X-axis.
- BA□MS□□ : ø7 (P15 ISA-SXM Refer to the bottom plan view.)
- BB□□□□□ : ø9 (P18 ISA-MXM Refer to the bottom plan view.)
- BC□□□□□ : ø9 (P19 ISA-MXM Refer to the bottom plan view.)
- BD□□□□□ : ø9 (P20 ISA-MXMX Refer to the bottom plan view.)
- BE□□□□□ : ø9 (P26 ISA-LXM Refer to the bottom plan view.)
- BF□□□□□ : ø9 (P28 ISA-LXMX Refer to the bottom plan view.)




XYG+Z Axis type

- Affix the actuators using the through holes provided on the bottom surface of the X-axis (driving shaft / driven shaft).

- G1JH□□□ (Driving shaft) : ø9 (P30 ISA-LXUWX Refer to the bottom plan view.)
(Driven shaft) : ø7 (P15 ISA-SXM Refer to the bottom plan view.)
- G2JH□□□ (Driving shaft) : ø9 (P30 ISA-LXUWX Refer to the bottom plan view.)
(Driven shaft) : ø7 (P15 ISA-SXM Refer to the bottom plan view.)



Cartesian Robots Series **System Configurations**

ISPA/ICSPA Catalog **66**